


NBFL AUX PINOUTS

A1



Copying of image is prohibited

24	23	22	21	20	19	18	17	16	15	14	13
12	11	10	9	8	7	6	5	4	3	2	1

A2



16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

A2 Connector	
1	
2	
3	EGT 2
4	Ign 5
5	Switch 3
6	WBO Ip
7	WBO HTR
8	WBO Rcal
9	
10	
11	Knock 2
12	Ign 6
13	Switch 3
14	WBO VGND
15	WBO 12v Htr
16	WBO Vs

A1 Connector	
1	HB1+
2	IGN 4
3	Ana 1
4	Ana 3
5	Ana 5
6	RS323 TXD
7	CAN L
8	CAM 2
9	
10	HB1-
11	SGND
12	5V
13	
14	Ign 3
15	EGT 1
16	Ana 2
17	Ana 4
18	Ana 6
19	CAN H
20	Flex Fuel
21	
22	
23	SGND
24	5V

STOCK FUNCTIONS

Output	Function	Function 2
aux 1	Fuel Pump	
aux 2	CLT fan	
aux 3	Boost	
aux 4	Tacho	
aux 5	Idle	
aux 6	AC Clutch	Pin 15 (A2)
Switch 1	Clutch Switch	
Switch 2	AC switch	Pin 12 (A2)
Inj 5	ALT Warn	
Inj 6	CEL	
HB 1-	Main relay	
HB 2+	Alternator	

